



User Manual

Model: Aspiring
Griffon 4

EN



Модель: Aspiring
Griffon 4

Official importer and distributor in
Ukraine – Himexpo Co., LTD
Address: Ukraine, Kiev, ul. Zochych
26A
Tel: +380 98 0982650
www.aspiring.ua

All rights reserved. No written
reproduction, publication, transfer of
this material is allowed with out
written permission of the
manufacturer.

Notice Before Use

1. Please use original high-speed class 1A TF card to storage video, unless it may not be compatible with this device indicate "file error" or "SD card error", this device max support 512GB TF card.
2. You must format memory card when you use this device at first time, if memory card inside have other video or picture it can not be read by device.
3. Pay attention to the insert direction of the card. If insert card from the wrong side, it may damage the device and TF card.
4. Please remove off the car charger lighter with your car when you do not use this dvr device like parking, otherwise your car engine start big instant electricity current probably burn out your dvr device.
5. This dvr device special use for car, please use it inside car with car charger, if no car charger recharging, its built-in battery very very small, sometimes may can not be turned on successfully because of no enough electricity.
6. This device only allow electricity 5V 2A, so please DO NOT use any home charger or USB cable to recharge, you MUST use our original car charger to do recharging, because some home charger adapter have 12V output, it is not suitable, it probably burn out the dvr device. Or sometimes comes out strange squeaky noisy sound because of current not compatible.

Installation Instructions



1. installation method

Mount the rear camera above the inside of the windshield

2. Dash cam Installation method

A. Dash cam installation position


The recommended installation area is shown in the figure. Hide the connection wire along the front windshield into the ceiling and access. The fuse box through the A-pillar.

B. Take power from the safety box

With special intelligent voltage drop line, 24-hour parking monitoring needs to be connected to normal power, low voltage automatic power off, to protect the battery from loss of power;

C. Cigarette lighter takes electricity

Use the same method to hide the line through the same path on the passenger side, and connect the central control cigarette lighter under the passenger's storage compartment to obtain power.



Tips: The standard length of the power cord and intelligent voltage reduction cable of this product is 3.5 meters. Depending on the model, the location of the safety box will be different; please refer to the owner's manual for details

Use a dashcam

Option 1

When you start the engine, the dashcam will automatically turn on, and when you stop the engine, it will automatically turn off.

Option 2

When the dashcam is turned off, simply hold down the power button for 5 seconds to turn it on. When the dashcam has been turned on, Hold down the power button for 3 seconds to turn it off.



1. Record standard videos
2. Video length
3. Video resolution
4. Date
5. Time
6. Discover enough satellites
7. Microphone status
8. Collision detection enabled
9. Memory card status
10. Wireless network status


Tip:

Press the corresponding bottom button to achieve the corresponding function. When the camera is triggered to lock the file, the flash point will turn yellow.

4. View and delete videos and photos

Press to enter the main menu, and then press . Select File Explorer.

Finally, click **OK** to view all the recorded videos and photos.



*Video_Front includes all standard videos recorded by the front camera.


*Video_Front_Lock includes all the locked videos recorded by the front camera when a collision occurs while driving or parking, as well as the videos where manual locking is pressed on the recording interface.

"Image Front" includes photos taken by the front camera.

*Video Back contains standard videos recorded by the rear camera.

"Video Back_Lock" contains all the lock videos recorded by the rear cameras when a collision occurs during driving or parking, as well as the videos where manual lock is pressed on the recording interface.

Image Back contains the photos taken by the rear camera.



Press briefly to select a file, and then press **OK** to play it.

Long press or to pop up a window to lock or unlock the selected file; to pop up a window for deleting the selected file

Long press to pop up a window for deleting the selected file.



Connect the dashcam to the application

Step 1

For iPhones, you can enter the Apple app store and search for "Lufeng Zhe" to download and install.

For Android phones, you can enter the App Store and search for "Lufeng Zhe" to download and install. You can also go to the "System Settings > WiFi Information" page, scan the QR code to download and install.



Step 2

Make sure the dashcam is turned on and the distance between the mobile device and the camera is within 5 meters.

Step 3

Navigate to "System Settings > WiFi Information", click "OK", and enable the WiFi of the dashcam.

Step 4 Open the Pelsee Cam App and grant the necessary permissions. Click "Add Camera" to check the wizard and start the connection.	Camera file View and manage your camera files by clicking icon  on the home page. From here, you can view all your videos and photos, and select a file to delete or download. ① Loop: Standard video from the front and rear cameras Snapshot: Photos captured from the front and rear cameras Lock: The front and rear cameras lock the video F: Video or photo taken by the front camera R: Videos or photos taken by the rear camera ② Click the "Select" button on the upper right corner to choose whether to download the file to your mobile device or delete the file. After downloading the file, you can edit it or directly share it on social media.  Note: After connecting to WiFi, the recorder cannot be operated.	Settings Press  to enter the menu, then press  to select "System Settings", and finally press" OK to view or modify the Settings. 1 Video resolution Change the resolution of the front camera. The options include 1080P, 2.5K and 4K. ② Loop record Change the recording time of each video. You can choose one minute. Two minutes and three minutes. ③ Frequency Change the screen refresh rate between 50Hz and 60hz .	4 Collision detection sensitivity Set the sensitivity of the g sensor for collision detection during driving. Select "low", "medium", "high" or "off" as needed. If set to high, the camera will automatically lock the current video in case of a minor collision. If set to Low, the camera will automatically lock the current video in case of a severe collision. The flashing yellow dot in the upper left corner indicates that the video is locked. 5 Parking monitor (appears when connected to the hardline kit) Enable any sensitivity level to activate the parking monitoring function. Higher sensitivity increases the possibility of triggering the recording when the car is parked. Selecting "Off" will disable this function. In this mode, the camera will turn on and start recording a 15-second locked video. After that, it will be turned off to protect the car battery. 6 Time-lapse recording(appears when connecting the hardwire kit) Enable this function to compress videos at 1 frame per second, 2 frames per second, 5 frames per second or turn it off 7 Delay recording duration (displayed when connecting the hardwire kit) Set the recording duration of the time-lapse video. The options include 12 hours, 24 hours, 48 hours and 72 hours. 8 Recording Turn on/off the recording function when recording. 9 Videowatermar Play back the file, font watermark, on or off (10) WDR In this mode, the recorder can capture high-quality images even in environments with too little or too much light, and it can be turned on or off.	11 No-light night vision It can capture clear images of objects within the frame even in low-light conditions. It can be turned on and off. 12 Rear camera preview Set the preview direction of the rear camera. No Change: Do not change the current view. Flip up and down: Flip the view of the rear camera up and down. Rearview mirror: Reflect the perspective of the rear camera from left to right. Flip and rearview mirror: The rear camera view can be flipped up and down, and the rear camera view can be flipped left and right. 13 Volume settings Turn up or down the volume of the dashcam. 14 Key click sound The sound feedback when turning on or off the buttons. 15 Screen saver Set the time to enter screen saver mode after a period of inactivity. The options include off, 1 minute, and 3 minutes. 16 Unit of speed Switching different speed units is displayed on the screen. 17 Time zone Select your time zone. 18 Language settings Select the language of the dashboard camera	19. Display date/time Display/hide the date, time 20. Wi-Fi information Turn on and off WiFi; Get the QR code to download the App. Check the WiFi name and password of the dashcam. 21. Date and time Settings Configure the date and time, date format and clock format of the dashboard camera. 22. Disk formatting Format your memory card. 23. Version information Check the camera software version (which may be inquired when seeking technical support) and contact information. 24. Restore factory settings Restore the dashcam to factory Settings.	
--	---	--	---	--	--	--



Інструкція користувача UA



Модель: Aspiring Griffon 4

Офіційний імпортер та дистриб'ютор
на території України – ТОВ «Хіме́кспо»
Адреса: Україна, м. Київ, вул. Зодчих
26-а
Тел: +380 98 098 26 50
Технічна підтримка: +38 098 0490911
www.aspiring.ua
Авторські права © Всі права захищені.
Без письмового дозволу виробника
заборонено копіювання, публікація
або передача даного

Умови зберігання та використання (безпеки)

- 1) Будь ласка, використовуйте пристрій тільки при нормальних температурах, не піддавайте пристрій впливу температур, які корпус не може витримати.
- 2) Не використовуйте пристрій в надзвичайно вологому середовищі, не допускайте потрапляння вологи або дощу на пристрій.
- 3) Не намагайтеся відкрити корпус пристрою для ремонту, якщо який-небудь вузол несправний. Будь ласка, зверніться до сервісного центру для професійного обслуговування.
- 4) Не використовуйте сильних хімікатів, розчинників чи миючих засобів для очищення пристрою.
- 5) Не направляйте камеру безпосередньо на сонце або інші джерела світла з підвищеною яскравістю, щоб уникнути пошкодження оптичних вузлів пристрою.
- 6) Не використовуйте пристрій в надзвичайно запиленіх умовах, щоб уникнути забруднення об'єктива та інших вузлів камери, так як це може позначитися на її роботі.


Інструкція з встановлення



1. **Спосіб встановлення**
Встановіть задню камеру у верхній частині внутрішньої сторони лобового скла або під номером автомобіля.
2. **Спосіб встановлення відеореєстратора (dash cam)**
А. Місце встановлення відеореєстратора
Рекомендована зона встановлення показана на зображенні. Сховайте кабель підключення вздовж переднього лобового скла, проклавши його через стелю та далі до блоку запобіжників через стійку А (A-pillar).
- В. Підключення живлення від блоку запобіжників**
Використовуйте спеціальний інтелектуальний АСС кабель (не йде в комплекті) з пониженням напруги. Для цілодобового режиму паркувального моніторингу пристрій необхідно підключити до постійного живлення. Передбачено автоматичне відключення при низькій напрузі, щоб запобігти розрядженню акумулятора.
- С. Підключення живлення від прикурювача**
відповідним кабелем з комплекту.

Живлення через прикурювач

Використовуйте той самий спосіб прокладання кабелю, приховуючи його тим самим шляхом з боку пасажирів, та під'єднайте його до прикурювача центральної консолі, розташованого під бардачком пасажира, щоб отримати живлення.



Порада: Стандартна довжина кабелю живлення та АСС кабелю з пониженням напруги для цього продукту становить 3,5 метра. Залежно від моделі автомобіля розташування блоку запобіжників може відрізнятися; для деталей зверніться до інструкції з експлуатації автомобіля.

Використання відеореєстратора

Коли ви запускаєте двигун, відеореєстратор автоматично вмикається, а коли ви зупиняєте двигун — автоматично вимикається.




1. Стандартний запис відео
2. Тривалість відео
3. Роздільна здатність відео
4. Дата
5. Час
6. Виявлено достатню кількість супутників
7. Статус мікрофона
8. Увімкнено виявлення зіткнень
9. Статус карти пам'яті
10. Статус бездротової мережі

Порада:
Натисніть відповідну нижню кнопку, щоб активувати відповідну функцію. Коли камера спрацює та файл блокується, індикатор блимання стане жовтим.


4. Перегляд і видалення відео та фото

Натисніть , щоб увійти в головне меню, а потім натисніть і виберіть File Explorer (Провідник файлів).

Після цього натисніть **ОК**, щоб переглянути всі записані відео та фотографії.



****Video_Front**** містить усі стандартні відеозаписи, зроблені передньою камерою.
****Video_Front_Lock**** містить усі заблоковані відео з передньої камери, записані під час зіткнення під час руху або паркування, а також відео, які були заблоковані вручну кнопкою на екрані запису.
****Image_Front**** містить фотографії, зроблені передньою камерою.
****Video_Back**** містить стандартні відеозаписи, зроблені задньою камерою.
****Video_Back_Lock**** містить усі заблоковані відео з задньої камери, записані під час зіткнення під час руху або паркування, а також відео, які були заблоковані вручну кнопкою на екрані запису.
****Image_Back**** містить фотографії, зроблені задньою камерою.



Коротко натисніть кнопку , щоб вибрати файл, а потім натисніть **ОК**, щоб його відтворити.

Тривале натискання кнопки або відкриває спливаюче вікно для **блокування або розблокування вибраного файлу**, а також для **видалення вибраного файлу**.

Тривале натискання кнопки відкриває спливаюче вікно для **видалення вибраного файлу**.



Підключення відеореєстратора до застосунку

Крок 1
Для iPhone:
Перейдіть до **Apple App Store** і знайдіть застосунок **"Lufeng Zhe"**, щоб завантажити та встановити його. Також можна перейти до **"Налаштування системи > Інформація Wi-Fi"** і відсканувати QR-код для завантаження та встановлення застосунку.



Крок 2
Переконайтеся, що відеореєстратор увімкнений, а відстань між мобільним пристроєм і камерою становить не більше 5 метрів.

Крок 3
Перейдіть до **"Налаштування системи > Інформація Wi-Fi"**, натисніть **ОК** та увімкніть Wi-Fi відеореєстратора.

Примітка: Компанія-виробник зберігає за собою право вносити в конструкцію пристрою зміни та/або модифікації без попереднього повідомлення користувачів про таке.

--	--	--	--	--	--	--